



This "easy-to-make" stretcher holds the bathing suit securely, making it easy to apply sequins and other decorations.

What you need:

- 10 feet** 1/2" PVC pipe
8 90° connectors
4 "T" connectors
-

Cut the pipe into:

- 6** 3" pieces
2 6" pieces
2 12" pieces
4 15½" pieces

(Use a hacksaw to cut the pipe.)

Assemble as shown

DO NOT USE GLUE!

You will want to use sandpaper on any rough edges, to prevent "catching" on the bathing suit material.